

# CITROEN

**FRONT WHEEL DRIVE**

**“Twelve” & “Fifteen” Models**

# REPAIR MANUAL

**ILLUSTRATIONS**

**1938**



**1950**

CITROEN CARS, LIMITED,  
TRADING ESTATE,  
SLOUGH, ENGLAND.

REPRINTED OCTOBER 1956

# INDEX OF ILLUSTRATIONS IN REPAIR MANUAL

| SECTION | PAGE NO. | DESCRIPTION                                                                          |
|---------|----------|--------------------------------------------------------------------------------------|
| ENGINE  | 1        | Lifting engine.                                                                      |
|         | 2        | Various tools.                                                                       |
|         | 2A       | stand for engine when removed.                                                       |
|         | 3        | Clutch control.                                                                      |
|         | 4        | Timing distributor.                                                                  |
|         | 5        | Cylinder head : sequence of tightening nuts.                                         |
|         | 7        | Engine assembly : longitudinal section.                                              |
|         | 8        | Engine assembly : cross section.                                                     |
|         | 9        | Replacing valve seat or guide.                                                       |
|         | 10       | Oil pump assembly.                                                                   |
|         | 11       | Fan and water pump assembly.                                                         |
|         | 12       | Spring testing.                                                                      |
|         | 12A      | Fitting sparking plug housings.                                                      |
|         | 13       | Adjustment of oil pump.                                                              |
|         | 14       | Water pump bush.                                                                     |
|         | 14A      | Fitting bearings by means of shims.                                                  |
|         | 15       | Boring and alignment of oil baffles.                                                 |
|         | 15A      | Fitting of oil baffle packing.                                                       |
|         | 16       | Fitting gudgeon pin circlips.                                                        |
|         | 17       | Precautions when assembling (sump gaskets).                                          |
|         | 17A      | Engine stands.                                                                       |
|         | 17B      | Fitting pistons into barrels.                                                        |
|         | 18       | Gauging height of barrels.                                                           |
|         | 19       | Setting timing wheels.                                                               |
|         | 20       | Water pump and dynamo driving shaft.                                                 |
|         | 21       | Carburettor : section and external views.                                            |
|         | 22       | Air intake silencer : sectional views.                                               |
|         | 22A      | Petrol pump : assembly and vertical section.                                         |
|         | 22B      | Petrol pump : checking for air leaks.                                                |
| CLUTCH  | 6        | Adjustment of gear locking device (light).                                           |
|         | 23       | Clutch : assembly and section.                                                       |
|         | 24       | Toggle adjustment.                                                                   |
|         | 24A      | Toggle adjustment (simplified method).                                               |
| GEARBOX | 25       | Stand for dismantling and re-assembling gearbox.                                     |
|         | 26       | Gearbox assembly : longitudinal section.                                             |
|         | 27       | Extractor for removing coupling flange. Bar for keeping opposite flange in position. |



# INDEX OF ILLUSTRATIONS IN REPAIR MANUAL

| SECTION             | PAGE NO. | DESCRIPTION                                                                          |
|---------------------|----------|--------------------------------------------------------------------------------------|
| GEARBOX (Continued) | 28       | Extraction of differential bearing.                                                  |
|                     | 29       | Gearbox cover, forks, gear lock (light type).                                        |
|                     | 30       | Mounting of fixing plates.                                                           |
|                     | 31       | Fitting synchromesh gear.                                                            |
|                     | 32       | Assembling gearbox : various mandrels and spanners.                                  |
|                     | 33       | Rectification of satellite thrust faces.                                             |
|                     | 34       | Stop tool for tightening layshaft front bearing lock nut.                            |
|                     | 35       | Adjustment of crown wheel and bevel pinion.                                          |
|                     | 35A      | Adjustment of crown wheel and bevel pinion (simplified method).                      |
| FRONT AXLE          | 36       | Adjustment of differential bearings.                                                 |
|                     | 37       | Extraction of ball pins.                                                             |
|                     | 38       | Assembly of silentbloc and torsion bar.                                              |
|                     | 39       | Mounting lower arm.                                                                  |
|                     | 40       | Fitting of torsion bars.                                                             |
|                     | 41       | Vertical section through hub and swivel centre-line.                                 |
|                     | 42       | Dismantling hubs and ball-races.                                                     |
|                     | 43       | Dismantling steering arm and outer ball-race retaining ring.                         |
|                     | 44       | Dismantling upper and lower swivel balls.                                            |
|                     | 45       | Section on centre-line of upper link.                                                |
|                     | 46       | Dismantling and assembling serrated shaft.                                           |
|                     | 47       | Dismantling and assembling nut for stub axle inner ball-race.                        |
|                     | 47A      | Fitting drive shafts.                                                                |
|                     | 48       | Removing stub axle and inner ball-race.                                              |
|                     | 48A      | Extractor for outer ball-race (outer groove broken). Extractor for inner ball-race.  |
|                     | 49       | Brake back plate assembly.                                                           |
|                     | 50       | Fitting or removing brake shoe return spring.                                        |
|                     | 51       | Flaring adjusting cams of brake shoes.                                               |
|                     | 52       | Replacement of wheel studs.                                                          |
|                     | 53       | Rectification of brake drums.                                                        |
|                     | 54       | Assembly of shafts.                                                                  |
|                     | 55       | Dismantling drive shafts.                                                            |
|                     | 56       | Dismantling drive shafts.                                                            |
|                     | 57       | Assembly of drive shafts.                                                            |
|                     | 58       | Assembly of drive shafts.                                                            |
|                     | 59       | Reboring spline housing of coupling.                                                 |
|                     | 60       | Assembly of stub axle end and ball-race into swivel. Tool for dismantling stub axle. |
|                     | 61       | Checking concentricity of brake linings.                                             |

# INDEX OF ILLUSTRATIONS IN REPAIR MANUAL

| SECTION              | PAGE NO. | DESCRIPTION                                                                                    |
|----------------------|----------|------------------------------------------------------------------------------------------------|
| STEERING             | 62       | Removing and refitting steering wheel.                                                         |
|                      | 63       | Steering assembly : longitudinal section.                                                      |
|                      | 64       | Assembly of ball pins.                                                                         |
|                      | 65       | Holding rack and pinion gear in vice.                                                          |
|                      | 66       | Various tools                                                                                  |
|                      | 67       | Adjusting length of track rod.                                                                 |
| REAR AXLE            | 67A      | Raising rear axle.                                                                             |
|                      | 68       | Dismantling early type axle.                                                                   |
|                      | 69       | Positioning rear axle.                                                                         |
|                      | 70       | Rear axle assembly : plan view                                                                 |
|                      | 71       | Removing torsion bars.                                                                         |
|                      | 72       | Rear link arm.                                                                                 |
|                      | 73       | Assembly of brake back plate.                                                                  |
|                      | 74       | Checking camber and toe-in of rear axle.                                                       |
|                      | 75       | Checking carber and toe-in of rear axle.                                                       |
|                      | 76       | rectification of brake drums.                                                                  |
|                      | 77       | Dismantling and assembling silentbloes of support brackets.                                    |
|                      | 78       | Setting rear link arm in relation with flange of rear crossmember when adjusting torsion bars. |
| SUSPENSION           | 79       | Checking lateral adjustment of axle.                                                           |
|                      | 80       | Checking concentricity of brake linings.                                                       |
| SUSPENSION           | 81       | Refitting 'Spicer' shockabsorbers.                                                             |
|                      | 81A      | Refitting 'Spicer' shockabsorbers.                                                             |
| GEAR CHANGE ASSEMBLY | 82       | Selector assembly.                                                                             |
| BRAKE                | 83       | Removing and fitting master cylinder.                                                          |
|                      | 84       | Master cylinder assembly.                                                                      |
| ELECTRICAL EQUIPMENT | 85       | Automatic advance ignition curves.                                                             |
|                      | 86       | Dynamo assembly.                                                                               |
|                      | 87       | Dynamo assembly.                                                                               |
|                      | 88       | Assembly of induction coils and pole-pieces, dynamo and starter motor.                         |
|                      | 89       | Starter motor assembly.                                                                        |
|                      | 90       | Starter motor assembly.                                                                        |
|                      | 98       | Wiring diagram.                                                                                |
|                      | 99       | Wiring diagram.                                                                                |

# INDEX OF ILLUSTRATIONS IN REPAIR MANUAL

| SECTION     | PAGE NO. | DESCRIPTION                     |
|-------------|----------|---------------------------------|
| ADJUSTMENTS | 91       | Checking caster angle.          |
|             | 92       | Checking lengths of track rods. |
|             | 93       | Checking steering lock.         |
|             | 94       | Checking wheel camber.          |
|             | 94A      | Weight distribution.            |
|             | 95       | Checking wheels.                |
|             | 96       | Checking balance of wheels.     |
|             | 97       | Adjusting headlamps.            |
| BODYWORK    | 100      | Realignment of hull.            |
|             | 101      | Realignment of hull.            |

— ENGINE —

— LIFTING ENGINE —

SLING IN POSITION.

DIMENSIONS CONFORM TO STANDARDS  
CNM 601 OR CNM 602 FOR LIFTING  
CHAINS, RINGS AND EYES ACCORDING  
TO GENERAL PRACTICE.

MAXIMUM LOAD: 250 KG (4.75 cwt)

ANNEALED MILD STEEL.




Fig.2. - PLUG SPANNER  
1601-T




Fig.1. - EXTRACTOR FOR BATTERY  
TERMINAL  
2200-T




Fig.4. - APPLICATION OF COMPRESSOR




Fig.3. - STUD EXTRACTOR  
2410-T








Fig.5. - VALVE SPRING COMPRESSOR

1611-T




## — CLUTCH CONTROL —

SETTING AND ADJUSTING INNER AND OUTER CLUTCH CABLES.ADJUSTMENT OF CLUTCH PEDAL HEIGHT.VIEW SHOWING CLUTCH CABLE IN POSITION.ADJUSTMENT OF OUTER CABLE


When declutching, outer cable must remain seated on cable guide 4.

— TIMING DISTRIBUTOR —

HOW TO USE LOCATING PIN.




TIMING INSTRUMENT IN POSITION.




TIMING INSTRUMENT.  
(1691T)

— FIRST READING —



FIRST ADJUSTMENT : ENGINE IS SET AT 8° ON FLYWHEEL. 6mm. PIN IS ENGAGED IN FLYWHEEL SLOT AND LAMP IS ALIGHT. CHECK NEEDLE POSITION.

— SECOND READING —




SECOND ADJUSTMENT : TURN DISTRIBUTOR BODY ANTI-CLOCKWISE TO INCREASE ADVANCE BY 4°. NEEDLE SHOWS 4° MORE THAN PREVIOUS READING.

## — ENGINE —

## — CYLINDER HEAD —

Fig. 1. - SEQUENCE FOR TIGHTENING CYLINDER HEAD NUTS.



| TIGHTNESS OF CYLINDER HEAD NUTS | IN METER - KILOS    |   | IN FOOT - POUNDS |  |
|---------------------------------|---------------------|---|------------------|--|
|                                 | 1st. TIGHTENING     | 3 | 21.7             |  |
|                                 | 2nd. TIGHTENING     | 5 | 36.17            |  |
|                                 | TIGHTENING WHEN HOT | 5 | 36.17            |  |

IT IS RECOMMENDED TO TIGHTEN CYLINDER HEAD NUTS IN THE ORDER STATED : THE DEGREE OF TIGHTNESS INDICATED MUST BE STRICTLY ADHERED TO AND OBTAINED BY USING TORSION SPANNER.

THIS SPANNER IS GRADUATED IN METER-KILOS AND USED WITH 12.7mm. SOCKET (2465T)


WHEN EFFORT HAS REACHED CORRECT POINT ON GRADUATION AND ARTICULATION "A" FOLDS, STOP TIGHTENING. ARTICULATION "A" MUST NEVER CONTACT BODY OF SPANNER IN "B".

Fig. 2. - TORSION SPANNER.  
(2470T)




— ADJUSTMENT OF GEAR LOCKING DEVICE, LIGHT —


LONGITUDINAL SECTION ON CENTRE LINE, SHOWING TAPERED END OF GEAR LOCKING ROD.



FRONT VIEW SHOWING ADJUSTABLE STOP FOR CLUTCH FORK AND SECTIONAL VIEW THROUGH FORK SHAFTS.




SIDE VIEW SHOWING FORK STOP ADJUSTMENT.




## — ENGINE —

## — ASSEMBLY, LONGITUDINAL SECTION —




— ASSEMBLY, CROSS SECTION —



## — REPLACING VALVE SEAT OR GUIDE —



REPLACING SEAT

EXTRACTING SEAT  
USING BLOW PIPE.





Prise up at 'a'  
with screwdriver.

MANDREL MR.3098-B FOR FITTING SEAT.


UNDERCUTTING SEAT FACEREPLACING GUIDE

MANDREL MR.1620-1 TO REMOVE GUIDE.


FITTING GUIDE

OIL PUMP ASSEMBLY


VERTICAL SECTION.




SECTION THROUGH RELEASE VALVE AND SPRING.



ORDER OF ASSEMBLY OF GASKETS AND MOUNTING OF PUMP BASE.



— FAN & WATER PUMP ASSEMBLY —— LONGITUDINAL SECTION ON CENTRE LINE —

### 1. CHECKING LENGTH OF SPRING :

PLACE SPRING TO BE CHECKED "1" BETWEEN FACES OF GUIDE "2"; DRAW SLIDE "3" INTO CONTACT: ARROW "4" COMES OPPOSITE FIGURE ON SCALE OF LENGTHS "5" INDICATING FREE LENGTH OF SPRING "1".

## 2. CHECKING LENGTH OF LOAD:

(a) PLACE STANDARD SPRING "6" (OR "12" ACCORDING TO REQUIREMENTS) IN TWO HOLES "7" AND DRAWSLIDE INTO CONTACT BY MEANS OF HAND-WHEEL "9".

(b) BRING SPRING TO BE TESTED "1" UNDER LOAD INDICATED IN BOOK BY MEANS OF HAND-WHEEL "9". READ THE LENGTH SHOWN BY ARROW "4" ON LENGTH SCALE "5".

(C) READ ON SCALE { 10 (in kilogrammes) OPPOSITE ARROW 11 (IF USING STANDARD SPRING 6) } CORRESPONDING  
 { 14 (in kilogrammes) OPPOSITE ARROW 13 (IF USING STANDARD SPRING 12) } LOADING.

Fig. 1. - SPRING TESTING APPARATUS.  
(2420 T)




Fig. 2. - STANDARD SPRINGS.



SPRING, COMPRESSION.

1mm. PER 1 KG. LOAD.

(2421 T)

This spring is painted yellow.




SPRING, COMPRESSION.

1mm PER 2 KG LOAD.

(2422 T)

This spring is painted red.




— FITTING SPARKING PLUG HOUSINGS —

SCREW CONE 'A' INTO SPARKING PLUG THREADING TO EXERCISE PRESSURE ON BALLS.  
GIVE ONE TURN TO BODY 'B' BY MEANS OF SPANNER 19 mm. ACROSS FLATS.  
SCREW DOWN CONE 'A' AGAIN AND GIVE ONE MORE TURN TO BODY 'B'.  
THIS SHOULD BE SUFFICIENT TO ENSURE A WATER-TIGHT FIT.



## — ENGINE —

## — ADJUSTMENT OF OIL PUMP —



The pump to be tested fitted on a sump will be driven by an electric drill 1000-1500 R.P.M. (Normal speed usually marked on maker's name-plate)

USE WINTER GRADE OIL "MOBIL OIL ARCTIC"

NOTE: IF POSSIBLE HEAT OIL TO 150°F. The pressure indicated by gauge should remain between 28-31.5 lbs/sq.in.

IF THIS IS IMPOSSIBLE BRING OIL TO 68°F

The pressure indicated should remain between 32-35 lbs/sq.in.

TO BRING PRESSURE TO CORRECT FIGURE.

Screw up release valve control to increase pressure.

Unscrew release valve control to reduce pressure.

## — WATER PUMP BUSH —

Fig.1. - REAMING BUSH.




Fig.2. - MILLING IMPELLOR SEATING FACE.








Fig.3. - CHECKING MILLING OF IMPELLOR SEATING FACE.



— FITTING BEARINGS BY MEANS OF SHIMS —



Shims to give correct or  
original diameter at a.  
 $= 58.01 \begin{matrix} +0.025 \\ -0 \end{matrix}$

— BORING & ALIGNMENT OF OIL BAFFLES —USE OF APPARATUSCOMPOSITION OF APPARATUS (1665T)

- a SET SCREW FOR HANDLE
- b WASHER
- c HANDLE
- d LOCK-NUT FOR CUTTER
- e SAFETY RING
- f CUTTER
- g ALIGNMENT BUSH
- h MANDREL CARRYING CUTTER

NOTE :- 3 SETS OF BUSHES "g" ARE PROVIDED.

1. OUTER DIA. 50 mm. (For bearings of original bore)
2. OUTER DIA. 49.5 mm. (For bearings after 1<sup>st</sup> cut)
3. OUTER DIA. 49 mm. (For bearings after 2<sup>nd</sup> cut)

The principal items of this apparatus can be used on all models.

— FITTING OF OIL BAFFLE PACKING —

Fig. 1. FITTING PACKINGS.




Fig. 2. —  
PREPARING PACKING FOR ASSEMBLY.









Fig. 3. —




— FITTING GUDGEON PIN CIRCLIPS —

— PRECAUTIONS WHEN ASSEMBLING —

FITTING OF SUMP GASKETS.

— Fig. 1. —




1. Gasket 'A' must butt against bearing cap 'B' (see at a)  
It must be flush with face against which timing case is fitted  
and thus preventing any oil escaping (see at b). It must be  
pinched under cap (see at c); add a piece of cork if necessary.
2. Make certain sump face fits snug at 'e' to gasket.  
If necessary add metal and reface. Stone down any sharp  
edges at 'f' without creating rounded or chamfered surfaces  
in order not to injure circular cap gasket 'C' when fitting  
sump.  
Ends 'f' of circular gasket 'C' in contact with gasket 'A'  
and under cap 'B' to be coated with 'HERMETIC'.

POSITION OF LOCK-PLATES FOR BIG END  
NUT FITTING.

Square-cornered flange of both  
lock-plates must butt at 'h' in  
order to prevent nuts rotating  
anti-clockwise.

— Fig. 2. —

Nut loosens this  
way.  
Flange prevents  
nut loosening.




## — ENGINE —

## — ENGINE STANDS —


— Fig. 1. —

USE OF STAND MR. 3300.20  
FOR ENGINE IN  
INVERTED POSITION.




— Fig. 2. —


USE OF STAND MR. 3300.30  
FOR ENGINE IN  
UPRIGHT POSITION



STAND MR. 3300.20



STAND MR. 3300.30





— FITTING PISTONS INTO BARRELS —

Fig. 1. - USE OF RING.








Fig. 2. - RING  
(1656 T)



## — GAUGING HEIGHT OF BARRELS —



INSTRUMENT MR. 3377.

1. PREPARING INSTRUMENT.

PLACE STAND MR. 3377 FITTED WITH CLOCK GAUGE ON SURFACE PLATE OR STRAIGHT EDGE WITH A READING OF APPROX. 2mm. INDICATED. BRING GRADUATED FACE TO ZERO.


2. MEASURING DEPTH AT MINIMUM HEIGHT (WITHOUT LOWER GASKET). Fig. 1.

PLACE INSTRUMENT PREPARED AS ABOVE ON BLOCK FACE WITH POINTER CONTACTING BARREL. TAKE READINGS AT 4 CARDINAL POINTS ON BARREL. TAKE AVERAGE.

3. MEASURING HEIGHT OF BARREL (GASKET IN POSITION) Fig. 2.

PLACE INSTRUMENT ON BARREL WITH POINTER CONTACTING CYLINDER BLOCK. THE DIFFERENCE IN READINGS SHOULD BE BETWEEN 0.05 AND 0.10

—SETTING TIMING WHEELS—




ENGINE BEING AT TOP  
DEAD CENTRE AT END OF  
COMPRESSION STROKE OF FIRST  
CYLINDER, THE CENTRES OF BOTH  
WHEELS AND TIMING MARK (line or  
centre-punch) OF CAMSHAFT WHEEL  
MUST BE IN STRAIGHT LINE.  
CRANKSHAFT WHEEL MAY BE MARKED  
(line or centre punch) :

1. ON TOOTH.
2. BETWEEN TEETH.

IN CASE 1. THE MARK IS ONE HALF-TOOTH TO  
THE RIGHT OF STRAIGHT LINE BETWEEN  
WHEEL CENTRES.


IN CASE 2. THE MARK IS SET ON STRAIGHT LINE  
BETWEEN WHEEL CENTRES.

## — WATER PUMP AND DYNAMO DRIVING SHAFT —

Fig.1. SECTION ON CENTRE LINE OF SHAFT.Fig.2. SPANNER  
(1640.T)

## — CARBURETTOR —


## — SECTION AND EXTERNAL VIEWS —




— AIR INTAKE SILENCER —

— SECTIONAL VIEWS —


— Fig. 1. — LONGITUDINAL SECTION.




— Fig. 2. — TRANSVERSE SECTION  
AT ab




— Fig. 3. — TRANSVERSE SECTION  
AT cd



— ASSEMBLY: VERTICAL SECTION —



— PETROL PUMP —— CHECKING FOR AIR LEAKS —FAULTY ASSEMBLY.Leak at pump assembly point.FAULTY DIAPHRAGM.Leak at operating arm orifice.




— ASSEMBLY AND SECTION —


— Fig. 1. —

LONGITUDINAL SECTION  
ON CENTRE LINE.

Remove same amount from both faces.




— Fig. 3. —



— Fig. 2. —

FRONT VIEW SHOWING TOGGLES  
AND CLUTCH HOUSING.



— Fig. 4. —



ON 6 SPRING CLUTCH, ONLY:

THE PRESSURE PLATE FACE IS NOT FLAT BUT SLIGHTLY CONCAVE.  
(See Fig. 2.)

## — TOGGLE ADJUSTMENT —

Fig. 1. - APPARATUS FOR ADJUSTING CLUTCH.  
1701.T.





Fig. 2 - MECHANISM IN POSITION "CLUTCH IN"

THESE DIMENSIONS CAN ONLY BE MEASURED WHEN MOUNTED ON FACE PLATE.



Fig. 3 - CHECKING ADJUSTMENT.

WHEN PIVOTED, FINGER C MUST SLIDE OVER UPPER FACE OF TOGGLE.



— TOGGLE ADJUSTMENT (SIMPLIFIED METHOD) —

Fig. 1. METHOD OF MOUNTING.





Fig. 2. BLOCK MR. 3457/11.

REMARKS: THIS ARRANGEMENT IS TO BE ADOPTED WHEN OTHER MEANS ARE NOT AVAILABLE.

DURING ADJUSTMENT IT IS NECESSARY TO APPLY MOTION TO THE TOGGLES EITHER BY A PRESS OR DRILLING MACHINE.



TIGHTEN 3 NUTS **a** SUCCESSIVELY WITH THE SAME NUMBER OF TURNS.



AFTER TIGHTENING WITH **a**, ENSURE THAT BLOCKS AT **b** ARE IN CONTACT ON RING AT **c**.


3 BLOCKS ARE NECESSARY FOR ADJUSTMENT.


—STAND FOR DISMANTLING & REASSEMBLING GEARBOX—

MR.3053

For any other information regarding this stand, please consult us.



- a: Square as above 250 x 250, 6 thick, with 4 feet.  
Base plate on circular 250 dia. with 3 feet.
- Top plate swivelling on base plate a.
  - Gearbox stand with 2 locating pins.
  - Locating pins.
  - Stand with 2 clips.
  - Clips.
  - Angle plate with locking screw.
  - Locking screw.
  - Sliding plate, fitting under gearbox.
- 





— EXTRACTOR FOR REMOVING COUPLING FLANGE —— BAR FOR KEEPING OPPOSITE FLANGE IN POSITION —

THIS EXTRACTOR COMPRISES A  
COUPLING FLANGE OF THE  
USUAL TYPE : 8, TO WHICH IS  
WELDED A THREADED BOSS :

D, THIS IS FITTED WITH A  
SCREW : C, WHICH  
PRESSES AGAINST THE  
END OF THE PLANET  
SHAFT.

Boss: 30 dia; 25 long.

Screw: 16 dia. x 200 pitch.

Length under head 90.

End pointed.

Head hexagonal.

31 across flats.

20 long.


EXTRACTOR MR. 3328

FLANGE TO BE  
EXTRACTED.

FLANGE TO BE  
HELD.

BAR MR 3352 IN POSITION.

BAR MR. 3352.






—GEARBOX—

— EXTRACTION OF DIFFERENTIAL BEARING —

USE OF EXTRACTOR






EXTRACTOR BODY 1750T.

SPLIT COLLET, RING, AND THRUST BLOCK 1753T.

## — COVER — FORKS — GEAR LOCK (LIGHT TYPE) —

LOCKING SELECTOR FORK SET-SCREW.


Each set screw holding the forks on their shafts must be locked with wire in such a manner that the section under tension is opposed to direction of bolt loosening.

DETAIL OF SELECTOR SHAFTS LOCKING DEVICE.COVER ASSEMBLY INVERTED SHOWING RESPECTIVE POSITION OF FORKS.




— MOUNTING OF FIXING PLATES —

DISTANCE BLOCK MR. 1525.



POSITIONING OF BRACKETS.

Brackets a and b must rest on each distance block at either end (see c and d)




## — GEARBOX —

## — FITTING SYNCHROMESH GEAR —

TOOL MR.3025 IS MADE OF A CITROEN FRONT WHEEL DRIVE "11" (LIGHT 15 OR BIG 15) SYNCHROMESH CENTRE SLIDE MODIFIED AS FOLLOWS. AFTER MODIFICATION THIS PART CANNOT BE USED IN A GEARBOX.


1. Anneal part.
2. Make 6 tapered grooves to receive balls as shown below.
3. Ease off all splines to get free movement of synchromesh ring.

— Fig. 1. —




PLACE SYNCHROMESH RING ON TOOL. PLACE 6 SPRINGS IN THEIR HOUSINGS. PLACE 6 BALLS IN GROOVES. PUSH SYNCHROMESH RING DOWN ON TOOL.

— Fig. 2. —





PLACE ASSEMBLY OF SYNCHROMESH RING ON TOOL. PUSH DOWN THE SYNCHROMESH RING TO RETURN THE BALLS.

— Fig. 3. —



CONTINUE TO PUSH DOWN RING TO FREE TOOL.





— Fig. 4. —



Each groove to be cut out from the middle spline of a group of 3 splines.



— ASSEMBLING GEARBOX —

1. VARIOUS MANDRELS.






2. SPANNERS.

FOR CLUTCH BELLHOUSING BOLTS.




## — RECTIFICATION OF SATELLITE THRUST FACES —


Fig. 1. USE OF TOOL.Fig. 2. HANDLE MR. 3094-2Fig. 3. PILOT MR. 3094-3

— STOP TOOL FOR TIGHTENING LAYSHAFT FRONT BEARING LOCKNUT —


LAYOUT SHOWING TOOL IN POSITION.



TOOL NO MR. 3139.




PLAN VIEW.



— ADJUSTMENT OF CROWN WHEEL AND BEVEL PINION —

Fig. 1. USE OF APPARATUS  
FOR POSITIONING BEVEL PINION.



APPARATUS 2044.T.


BEVEL PINION



PINION SETTING DIMENSION

MATCHING NUMBER

Fig. 2. USE OF CLOCK GAUGE  
FOR ADJUSTING MESHING  
CLEARANCE.



BRACKET FOR CLOCK GAUGE. 2041T.


CROWN WHEEL



MATCHING NUMBER

MESHING CLEARANCE IN  
HUNDREDTHS OF M/M.

— ADJUSTMENT OF CROWN WHEEL AND BEVEL PINION —  
(SIMPLIFIED METHOD)



IF APPARATUS 2040.T. SHOWN ON PAGE 35 IS NOT AVAILABLE USE THE METHOD AS DESCRIBED BELOW :

The outer circumference of the differential casing which locates the crown wheel is rectified to 110 m.m. diameter.

The distance from the centre of the crown wheel to the face of the bevel pinion is etched on the pinion face (see Page 35)

WITH BEVEL PINION FITTED IN PLACE, FIT THE DIFFERENTIAL, TIGHTEN BEARINGS TO ENSURE THAT THERE IS NO SIDE PLAY.

TO ADJUST BEVEL PINION, FIND THE DIFFERENCE BETWEEN PINION FACE AND OUTER CIRCUMFERENCE OF DIFFERENTIAL CASING.

EXAMPLE :


DIMENSION ETCHED ON PINION = 56,20mm  
RADIUS OF DIFFERENTIAL CASING = 55 mm  
DIFFERENCE = 56,20 - 55 = 1,20 mm

ADJUST THE PINION SO AS TO OBTAIN A GAP OF 1.20m.m. BETWEEN FRONT MACHINED FACE OF PINION AND RECTIFIED FACE OF DIFFERENTIAL CASING. (Care must be taken not to measure the pinion dimension from the pinion shaft cap which may stand proud of the pinion face)

MEASURE THIS DISTANCE WITH AN ORDINARY COMMERCIAL FEELER GAUGE (See illustration)

IN NO CIRCUMSTANCES IS ANY OTHER MEANS OF ADJUSTING CROWN WHEELS AND BEVEL PINIONS TO BE EMPLOYED.



— ADJUSTMENT OF DIFFERENTIAL BEARINGS —



— EXTRACTION OF BALL PINS —

Fig. 1. BALL PIN EXTRACTOR  
1964.T.






Fig. 2. USE OF BALL PIN EXTRACTOR.





IMPORTANT: DO NOT OMIT TO SCREW KNURLED  
CAP ON BALL PIN THREAD BEFORE PLACING  
EXTRACTOR. THIS IS TO AVOID DAMAGE TO  
THREADED END THROUGH PRESSURE OF  
EXTRACTOR STUD.

## — ASSEMBLY OF SILENTBLOC &amp; TORSION BAR —

HORIZONTAL SECTION ON CENTRE - LINE

## — FRONT AXLE —

## — MOUNTING LOWER ARM —

Fig. 1. SPANNER.  
(1880.T)

TOMMY BAR FOR BOX SPANNER MR. 3197-2.



— Fig. 2. —  
GAUGE MR. 3350.Upper shock  
absorber pin.

Fig. 3. —


USE OF GAUGE  
MR. 3350.Gauge is fitted on  
upper and lower shock-  
absorber pins.

Lower arm.



Lower shock absorber pin.

## — FITTING OF TORSION BARS —

ASSEMBLY SHOWING TORSION BAR BEING FITTED



DRAW-BAR MR.3349.


Nut, 10 dia. x 150 pitch  
welded on draw-bar.



DETAILS OF THRUST PIECE.

— FRONT AXLE —


41

— VERTICAL SECTION THROUGH HUB & SWIVEL CENTRE - LINE —



— FRONT AXLE —— DISMANTLING HUBS AND BALL-RACES —Fig. 1. EXTRACTING HUB.Fig. 2. EXTRACTING BALL-RACEFig. 3. SPANNER.  
(1810.T)

THIS SPANNER IS USED WITH  
TORSION WRENCH 2472.T.



TENSION SHOULD BE APPLIED  
PERPENDICULARLY TO LENGTH OF  
SPANNER AS SHOWN.

— DISMANTLING STEERING ARM & OUTER BALL-RACE RETAINING RING —

Fig.1. - REMOVING STEERING ARM




Fig.2 - USE OF SPANNER.




Fig.3. - SPANNER 1825.T.



— DISMANTLING UPPER & LOWER SWIVEL BALLS —

Fig. 1. - BALL EXTRACTOR  
1850.T.





Fig. 3. - SPANNERS  
1852.T.









— FRONT AXLE —

45


— SECTION ON CENTRE-LINE OF UPPER LINK —



## — DISMANTLING &amp; ASSEMBLING SERRATED SHAFT —


ASSEMBLY SHOWING EXTRACTION  
OF SERRATED SHAFT.LONG PLUNGER  
MR. 3363-3SHORT PLUNGER.  
MR. 3363-2



SOCKET. MR. 3363-1



— FRONT AXLE —

— DISMANTLING & ASSEMBLING NUT FOR STUB AXLE INNER BALL - RACE —




— FRONT AXLE —— FITTING DRIVE SHAFTS —Fig. 1.- USE OF APPARATUS.Fig. 2.- VICE 1830.T.

— REMOVING STUB AXLE AND INNER BALL-RACE —

TOOL FOR REMOVING STUB AXLE.

1824.T.


— Fig. 1. —



REMOVING STUB AXLE

- SCREW A DOWN (RIGHT HAND OR LEFT HAND ACCORDING TO SIDE) TIGHTLY ON TO STUB AXLE END : 31.
- TURN B TO RIGHT ROUND A. (b FITS INTO SWIVEL)
- SCREW E ON SWIVEL.
- TURN B TO LEFT (KEEPING HANDLE A STEADY TO PREVENT IT FROM TURNING) A PUSHES STUB AXLE 31 WHICH COMES OUT OF BALLRACE : 18.
- TO FREE TOOL.  
UNSCREW E FROM SWIVEL.  
UNSCREW A FROM STUB AXLE.

— Fig. 2. —




REMOVING INNER BALLRACE

- PLACE BEARING I ON SWIVEL.
- PUSH ASSEMBLY G THROUGH BALLRACE: 18
- FIT ASSEMBLY A AND B OVER SHAFT G UNTIL ASSEMBLY TOUCHES BEARING I.
- SCREW A RIGHT HAND INTO B TO CLEAR HOLE FOR STOP PIN H.
- PUT STOP PIN H IN POSITION.
- TURN B RIGHT HAND (KEEPING A STEADY) UNTIL BALLRACE 18 TOUCHES BEARING I.
- PULL COMPLETE ASSEMBLY WITH BALLRACE 18 AWAY.
- TO FREE TOOL.  
WITHDRAW SHAFT G.

SOME BALLRACES CAN BE REMOVED WITH EXTRUDING TOOL.

## — FRONT AXLE —


EXTRACTOR FOR OUTER BALL RACE (OUTER GROOVE BROKEN) —  
EXTRACTOR FOR INNER BALL RACE —







## — FITTING OR REMOVING BRAKE SHOE RETURN SPRING —





Assembly showing  
pin being flared.

Pin to be flared

### Adjusting cam

Brake plate.

Socket MR3354-1.


Steel 819 Tempered and  
annealed.

Remove sharp edges.


**Socket MR.3354-1**

Steel 819 Tempered and annealed



Recess 2<sup>m</sup>/m or 3<sup>m</sup>/m



## — REPLACEMENT OF WHEEL STUDS —



— RECTIFICATION OF BRAKE DRUMS —



— FRONT AXLE —


— ASSEMBLY OF SHAFTS —

Sectional view.

— Fig. 1. —

— Fig. 2. —

Shim to reduce  
play at 'a'.




— FRONT AXLE —


— DISMANTLING DRIVE SHAFTS —

Dismantling yoke end of stub axle.

— Fig. 1. —




— Fig. 2. —



— Fig. 3. —

Removing yoke end of stub axle.



Spigot ball assembly.

Clearance for removing spider.

— Fig. 4. —

Removing double yoke.




Fig. 5.  
REMOVING SPIGOT BALL CASING.




Fig. 6.  
EXTRACTING SPIGOT CUP FROM STUB AXLE END.






Fig. 8.  
CHECK DEPTH OF  
SPIGOT PIN HOUSING.




Tolerance at a = 0 to 0,125 mm.

Fig. 7.  
EXTRACTING SPIGOT PIN FROM DRIVE SHAFT END.




— ASSEMBLY OF DRIVE SHAFTS —

Fig. 9.  
PLACING SPIDER AT STUB AXLE  
END.



Modified  
spigot pin.  
(see Fig. 11.)

Fig. 12. CHECKING POSITION OF  
INNER SPIGOT BALL.



Dimensions to be  
equal at these two  
points between  
0 and 0.17 mm.

BEARING HOUSING GAUGE 1910.T.

THREE POINT CONTACT GAUGE 1908.T.

Fig. 10.  
FITTING SPIGOT CUP.






Fig. 11.  
MODIFIED SPIGOT PIN.



GRIND ROUNDED PART AT  
BASE TO OBTAIN A FLAT FOR  
SEATING ON BALL TOP: 69. THIS  
PREVENTS PARTS FROM  
SEIZING WHILE SPIGOT CUP, 63  
IS BEING FORCED INTO POSITION.

Fig. 13. FITTING SPIDER AT  
DRIVESHAFT END.



## — FRONT AXLE —

## — ASSEMBLY OF DRIVE SHAFTS —

FITTING OF SPIGOT PIN




Fig. 15.

FITTING DOUBLE YOKE ON STUB AXLE END




Fig. 17.

FITTING CORK WASHER RETAINER




Fig. 16.

FITTING DRIVE SHAFT END TO DOUBLE YOKE





Fig. 18.

CHECKING FIT OF CIRCLIPS





— REBORING SPLINE HOUSING OF COUPLING —

— Fig. 1. —

DIAGRAM SHOWING ASSEMBLY BEING PREPARED






Fig 2  
c. GUIDE MR.1627-2



## —ASSEMBLY OF STUB AXLE END AND BALL-RACE INTO SWIVEL—

TOOL FOR DISMANTLING STUB AXLE

1824 T.

TOOL ALREADY MENTIONED  
ON ILLUSTRATION 48.FIG. 1. FITTING INNER BALL-RACE


- PLACE STUB AXLE 31 IN SWIVEL
- PLACE BALL-RACE 18 IN FRONT OF SWIVEL
- LOCK PART A ON STUB AXLE 31. (RIGHT OR LEFT ACCORDING TO SIDE)
- TURN B RIGHT KEEPING A STEADY BY MEANS OF HANDLE
- RELEASING TOOL —
- UNSCREW A (RIGHT OR LEFT ACCORDING TO SIDE)

FIG. 2. FITTING STUB AXLE AND SWIVEL ASSEMBLY CORRECTLY

- FIT LOCKWASHER FOR NUT: 17.
- SCREW NUT: 17 WITH SPANNER 1826-T (SEE ILLUSTRATION 47); BEND TAB INTO POSITION
- SCREW A ON AXLE 31 (RIGHT OR LEFT ACCORDING TO SIDE)
- TURN B RIGHT DRIVING B INTO SWIVEL. SCREW E ON SWIVEL.
- TURN B LEFT KEEPING A STEADY UNTIL BALL-RACE IS ON SEATING

— RELEASING TOOL —


- UNSCREW E, UNSCREW A. (RIGHT OR LEFT ACCORDING TO SIDE)

FIG. 3. FITTING OUTER STUB AXLE BALL-RACE

- PLACE DISTANCE PIECE: 16.
- PLACE BALL-RACE: 15, ON STUB AXLE 31.
- SCREW A ON STUB AXLE 31 (RIGHT OR LEFT ACCORDING TO SIDE)
- TURN B RIGHT, KEEPING A STEADY, TILL BALL-RACE 15 IS ON SEATING

— RELEASING TOOL —

- UNSCREW A (RIGHT OR LEFT ACCORDING TO SIDE)



— CHECKING CONCENTRICITY OF BRAKE LININGS —


CONCENTRICITY CHECKING APPARATUS

— Fig. 1. —

2100 T.


— Fig. 2. —

REGISTERING DIAMETER OF DRUM



- INSERT INSTRUMENT INTO DRUM
- BRING INDICATOR a, INTO CONTACT WITH DRUM AND DESCRIBE COMPLETE CIRCLE.
- LOCK INDICATOR AT SET POSITION WITH THUMB-SCREW b.

CHECKING CONCENTRICITY OF LININGS



- FIT INSTRUMENT ON STUB (WITH KEY REMOVED)
- PLACE INDICATOR: a, AS PREVIOUSLY SET ON LININGS, INDICATOR MUST REMAIN IN CONTACT THROUGHOUT CIRCUMFERENCE (IN ORDER TO OBTAIN THIS RESULT, ADJUST LININGS BY ECCENTRIC BUSHES; c, AND ADJUSTING CAMS AT REAR OF BACK-PLATE, NOT SHOWN)
- REMOVE BURRS ON LININGS WITH RASP.

AFTER CHECK, RELEASE CAMS TO ALLOW FITTING OF DRUM (FOR FINAL ADJUSTMENT OF CAMS, SEE OPERATION 150  
PARA. 2.

## — REMOVING AND REFITTING STEERING WHEEL —

Fig. 1. - LOCATING FIXED TUBE.









Fig. 2. REMOVING STEERING WHEEL.




— STEERING —— ASSEMBLY —SECTIONAL VIEW THROUGH CASINGDETAILS OF FITTING OF  
CONCENTRIC RUBBERSSECTIONAL VIEW THROUGH  
PINION HOUSING

## —STEERING—

## —ASSEMBLY OF BALL PINS—

FIG.1. SECTIONAL VIEW SHOWING BALL PINS



— Fig. 3. —

FIG.3. CHECKING TOLERANCE OF RING NUT





FIG.2. SECTIONAL VIEW THROUGH DOWEL PIN



— Fig.4. —

STEERING ARM





FIG.4. ASSEMBLY OF BALL PINS AT TRACK ROD END

—HOLDING RACK AND PINION GEAR IN VICE—

ASSEMBLY SHOWING USE OF CLAMP MR.1561





— STEERING —  
— VARIOUS TOOLS —

Fig.1. COMBINATION SPANNER FOR  
RETAINING TUBE AND RING NUT  
1976.T.




Fig.2. SPANNER FOR  
ADJUSTING NUT ON  
OUTER BALL PIN CUP.  
1870.T.









Fig.3. SPANNER FOR  
STEERING RACK  
TUBE CAP. 1975.T.





—ADJUSTING LENGTH OF TRACK ROD—

ASSEMBLY SHOWING USE OF GAUGE




67A


— REAR AXLE —

— RAISING REAR AXLE —

BRACKET MR.3300-110



TO BE FITTED ON JACK HEAD



— DISMANTLING EARLY TYPE AXLE —

Fig.1. USE OF SPANNER.




Fig.3. SPANNER FOR REAR HEIGHT ADJUSTMENT. 2304.T.






Fig.2. SPANNER 2050.T.



— REAR AXLE —


—POSITIONING REAR AXLE—

— Fig. 1. —



— Fig. 2. —

GAUGE MR. 3338




Thickness 6 to 10 mm.

— REAR AXLE —

70.


— ASSEMBLY: PLAN VIEW —





# — REAR AXLE —

## — REMOVING TORSION BAR —

ASSEMBLY SHOWING USE OF BLOCK



BLOCK MR.1578



— REAR AXLE  
— REAR LINK ARM —

Fig. 1.  
ASSEMBLY OF REAR LINK ARM







Fig. 2  
HOLDING LINK ARM BRACKETS DURING ASSEMBLY



— Fig. 3 —  
SET OF ANGLE PIECES MR. 3936




## — ASSEMBLY OF BRAKE BACK PLATE —





— CHECKING CAMBER AND TOE-IN OF REAR AXLE —


Fig. 1. CHECKING CAMBER.



CAMBER  
ANGLE  $1^{\circ}$  TO  $1^{\circ}30'$  GIVING  
7.3 TO 11.3 mm ON WHEEL  
RIM DIAMETER.

CHECKING GAUGE 2052.T.

Fig. 2. CHECKING TOE-IN.




TOE-IN  
 $0^{\circ}$  TO  $0^{\circ}15'$  GIVING  
0 TO 2 mm ON WHEEL RIM  
DIAMETER.

WORKING FACE OF GAUGE, MUST BE  
PERFECTLY SQUARE TO CENTRE LINE  
OF LATHE.  
ON STUB AXLES OF 30mm. DIAMETER  
A BUSH IS FITTED BETWEEN STUB  
AXLES AND GAUGE BODY.


### — CHECKING CAMBER AND TOE IN OF REAR AXLE —

TOOL. 2052.T.




— RECTIFICATION OF BRAKE DRUMS —

ASSEMBLY SHOWING USE OF MANDREL




## —DISMANTLING AND ASSEMBLING SILENTBLOCS OF SUPPORT BRACKETS—


ASSEMBLY SHOWING SILENTBLOCK BEING PUT IN POSITION




ASSEMBLY SHOWING SILENTBLOCK IN POSITION



DETAILS OF PLUNGER MR.3335-1




DETAILS OF GUIDE BLOCK MR.3335-2



— SETTING REAR LINK ARM IN RELATION WITH FLANGE OF REAR CROSSMEMBER  
WHEN ADJUSTING TORSION BARS —

ASSEMBLY SHOWING ANGLE OF ARM AND FLANGE




— CHECKING LATERAL ADJUSTMENT OF AXLE —USE OF GAUGE

WITH GAUGE APPLIED AGAINST HUB AS SHOWN, CIRCULAR MARKING "a" OF MOVING PIN "b" COMES OPPOSITE ONE OF THE DIVISIONS OF THE SCALE GRADUATED ON GUIDE "d".  
Note figure indicated.


APPLY GAUGE TO OPPOSITE HUB.

CIRCULAR MARKING (if axle is in correct adjustment) SHOULD COME OPPOSITE SAME DIVISION AS INDICATED ABOVE.

IF READINGS DIFFER (axle out of line) READJUST TIE-BAR TO BRING AXLE INTO CORRECT ADJUSTMENT.




GAUGE 2051.T.

— REAR AXLE —— CHECKING CONCENTRICITY OF BRAKE LININGS —— APPARATUS 2103-T —— Fig. 1. —REGISTERING DIA. OF DRUM




BRAKE DRUM EQUIPPED WITH S.P.I. OIL RETAINER WITH COMPLETE INNER TIMKEN BALL-RACE B, AND WITH OUTER TIMKEN BALL-RACE C.

- PLACE DRUM ON PIVOT
- PLACE INDICATOR RING ON PIVOT
- BRING INDICATOR a, IN CONTACT WITH DRUM, AND DESCRIBE A COMPLETE CIRCLE.
- LOCK INDICATOR AT SET POSITION WITH THUMBSCREW b.


— Fig. 2. —CHECKING CONCENTRICITY OF LININGS

- FIT INSTRUMENT ON STUB
- PLACE INDICATOR a, AS SET PREVIOUSLY, ON LININGS;
- INDICATOR MUST REMAIN IN CONTACT THROUGHOUT CIRCUMFERENCE. (IN ORDER TO OBTAIN THIS RESULT, ADJUST LININGS BY ECCENTRIC BUSHES, C AND ADJUSTING CAMS AT REAR OF BRAKE PLATE, NOT SHOWN)
- REMOVE BURRS ON LININGS WITH RASP.

AFTER CHECK RELEASE CAMS TO ALLOW FITTING OF DRUM (FOR FINAL ADJUSTMENT OF CAMS SEE №150, PARA.2)


— SUSPENSION —— REFILLING SPICER SHOCK ABSORBER —Fig. 1. USE OF APPARATUS.Fig. 3. GUIDE FOR VALVE.

SHOCK ABSORBER  
PLUG DRILLED  
AND WELDED  
IN FUNNEL.

Fig. 4. VALVE.



— REFILLING SPICER SHOCK ABSORBERS —




**Fig. 2. LEVER.**

Steel tube 15 1/2 dia.  
x 21 0/dia., 850 long


Steel tube 15 1/2 dia.  
x 21 0/dia.

Groove, half round,  
10 dia, for locking  
clip.




**Fig. 4. PIN.**

Two pins pressed in and  
welded on inside of  
channel only.



**Fig. 3. SHOCK ABSORBER  
LOCKING CLIP.**



Piano wire 2 mm dia.

## — GEAR CHANGE ASSEMBLY —

## — SELECTOR ASSEMBLY —

FIG. 1 PLAN VIEW




FIG. 2 SIDE VIEW





FIG. 3 - SPANNER 2430-T



— REMOVING AND FITTING MASTER CYLINDER —

Fig.1. HANDLE 2131.T.






Fig.2. SPANNER 2130.T.




SECTION ON LONGITUDINAL CENTRE LINE.




— ELECTRICAL EQUIPMENT —  
 — AUTOMATIC ADVANCE IGNITION CURVES —

CURVE FOR SUCTION CONTROL




CURVE FOR DISTRIBUTOR



— ELECTRICAL EQUIPMENT —

— DYNAMO ASSEMBLY —


LONGITUDINAL SECTION ON CENTRE LINE.



— DYNAMO ASSEMBLY —

END VIEWS

Fig. 1. INDUCTION COILS  
*View from opposite side to brushes*



INDUCTION COILS *wiring at positive brush*  
SHOWING HOW TO KEEP BRUSHES AWAY  
FROM ARMATURE WHILE ASSEMBLING

Fig. 2. INDUCTION COILS  
*View from brush end*








Fig. 3.



THE BRUSHES ARE HELD AWAY BY THE  
SPRINGS IN ORDER TO ALLOW THE  
ARMATURE TO BE FITTED

## — ASSEMBLY OF INDUCTION COILS AND POLE-PIECES DYNAMO AND STARTER MOTOR —


ASSEMBLY FOR PACKING COILS







— STARTER MOTOR ASSEMBLY —

LONGITUDINAL SECTION ON CENTRE LINE.





Return spring for starter  
pinion not shown.

— ELECTRICAL EQUIPMENT —— STARTER MOTOR ASSEMBLY —END VIEWS— Fig. 1. —ASSEMBLY OF INDUCTION COILS— Fig. 2. —ASSEMBLY OF BRUSHES

BRUSHES ARE HELD AWAY FROM ARMATURE INSIDE  
BRUSH CARRIERS BY SPRINGS, THUS ALLOWING  
PASSAGE OF ARMATURE


— CHECKING CASTER ANGLE —

DETAILS OF LOWER INDICATOR




NOTE: IMPORTANT DIMENSIONS UNDERLINED SHOULD BE CAREFULLY ADHERED TO. FACES MARKED ▼▼ SHOULD BE GROUND.

DETAILS OF PLUMB-BOB SUPPORT



ASSEMBLY SHOWING USE OF GAUGE



MR. 1767

MOUNTING GAUGE


- 1 REMOVE GREASERS ON UPPER AND LOWER LINK ARMS
- 2 MOUNT BRACKETS AS SHOWN
- 3 ADJUST LOWER INDICATOR SO THAT INNER FACE IS AS NEAR CONTACT OF CORD AS POSSIBLE WITHOUT TOUCHING.
- 4 ENSURE THAT PLUMB-BOB CORD FALLS BETWEEN MARKINGS CORRESPONDING TO GREASER TAPPING USED.

## — ADJUSTMENTS —

## — CHECKING LENGTHS OF TRACK RODS —


— Fig. 1. —

ASSEMBLY SHOWING USE OF GAUGE



DETAILS OF GAUGE

MR1590



DISTANCE  $L$  BETWEEN SOCKET ENDS AT ONE SIDE SHOULD EQUAL DISTANCE  $L'$  BETWEEN SOCKET ENDS AT OTHER SIDE TOLERANCE  $1\text{mm}$  (see fig. 1)

— CHECKING STEERING LOCK —

Fig. 1. USE OF GAUGE.





Fig. 2. STEERING LOCK GAUGE. 1890.T.



SETTING OF GAUGE.

| 7 & 11 FRONT WHEEL DRIVE | TYPE OF WHEEL  | READING | LENGTH 'L' |
|--------------------------|----------------|---------|------------|
|                          | STOP 140x40    | 18      | 570        |
|                          | STOP 150x40    | 12      | 564        |
|                          | STOP 160x40    | 5       | 557        |
|                          | PILOTE 155x400 | 23      | 575        |
|                          | PILOTE 165x400 | 18      | 570        |
|                          | PILOTE 185x400 | 11      | 563        |
|                          | BM 165x400     | 23      | 575        |

## — CHECKING WHEEL CAMBER —

Fig. 1.      USE OF GAUGE





Fig. 2. ENLARGED VIEW OF SCALE.

Plumb line must rest between  
two gauge lines.




GAUGE 2314.T.

— ADJUSTMENTS —

94A

— WEIGHT DISTRIBUTION —



WEIGHING MACHINE  
2310.T.

— ADJUSTMENTS —

— CHECKING WHEELS —

— Fig. 1. — LOCATING HEAVY PART







Fig. 3. POSITION OF WELDED BALANCE  
WEIGHT



— Fig. 2. — ASSEMBLY SHOWING WHEEL MOUNTED  
FOR BALANCING



— Fig. 4. — CHECKING DISTORTION OF RIM









— CHECKING BALANCE OF WHEELS —

APPARATUS MR. 3396.

IMPORTANT NOTE  
IN ORDER TO GIVE THE INSTRUMENT MAXIMUM  
SENSITIVITY BALL-RACES SHOULD BE OILED WITH  
THIN VASELINE ONLY.  
THE APPARATUS SHOULD BE PERFECTLY BALANCED.



— ADJUSTMENTS —  
— ADJUSTING HEADLAMPS —

Fig. 1. SCREEN MR. 1572.Fig. 2. FIXING CABLES ON LOWER LINK ARM BOSS.PLATE FOR FIXING UNDER GREASER.PLATE FOR FIXING ON SCREENFig 4. HOOKS ON REAR OF SCREEN TO HOLD CABLES AFTER USE.